

## INSTALLATION INSTRUCTIONS FOR PRE-FLEX PRESSED FELTLOK® FLOOR PROTECTORS

1. These Floor Protector Sets haven't been flex pressed, which enables for easy separation of hook from pad when only a pad needs to be replaced and you only have Sets in stock.
2. To flex press simply hold the pad with 1<sup>st</sup> finger and thumb between both hands with print on paper positioned for normal reading left to right (this ensures hooks engage) and flex 6X with firm pressure, this securely engages the hooks into the felt.
3. When attaching Replacement Pads to a hook component on a chair, assemble with the lighter, softer felt side engaging with the hook component, apply firm pressure with a back and forth motion across (90°) the Velcro® hook rows (hook orientation is easily discerned). This will securely engage hooks in 5 seconds for home use. In commercial settings we recommend the same positioning of the replacement pad, but then to use a power multi-tool with a triangular Velcro hook pad with 180 grit sand paper for 2 seconds, firm pressure at 20,000 rpm speed. We used a "Fein multimaster" Model FM350Q with excellent results.
4. Please visit our website [www.feltlok.com](http://www.feltlok.com) or call 1-651-687-9725 if you need assistance on maintenance, installation or to reorder.

Thank you

Doug Hanes

FeltLok Floor Protector Products