

FELTLOK® REPLACEMENT PAD INSTALLATION INSTRUCTIONS

1. Install with the softer, lighter colored side of the FeltLok pad engaging with the hook component for easiest attachment.
2. When attaching Replacement Pads, apply firm pressure using a back and forth motion across the Velcro® hook rows (hook orientation is easy to discern). This procedure will engage the hooks into the felt in 5 seconds.
3. In commercial settings it is recommended to position the replacement pad, then use a power multi-tool with a triangular shaped Velcro disk with 180 grit sand paper, 20,000 rpm for 2 seconds with medium/firm pressure. The high speed vibration will give an ultra hook engagement with the felt pad. The multitool brand we used was a “Fein” multimaster FMM 350Q Model, it worked excellent.
4. Please visit our website www.feltlok.com or call 1-651-687-9725 FeltLok if you need assistance on maintenance, installation, or to order.

Thank you

Doug Hanes

FeltLok Floor Protector Products